

62, QPL & KPL INSTRUCTION SHEET

Note: If the height from the floor to the bottom of boxspring exceeds 11", the PLX-18 Power-Lift Extension Kit will be needed. These extension kits can be purchased from your local retailer.

Step 1 Tap glide assembly into legs of cross supports until plastic insert is fully seated or install PLX-18 Extension Kits, if required. See View 1.

Step 2 For 62 and QPL cross support systems:

Loosely attach L-screw to clamp and slide onto square end of the cross support as indicated in View 2. Overlap cross supports and slide clamp onto both cross supports. Adjust cross support to width needed, and tighten L-screw.

For KPL cross support system:

Loosely attach L-screw to clamp and slide onto square end of the long cross support as indicated in View 2. Slide the short cross support over the long cross support and adjust to the width needed. Place clamp where cross supports overlap and tighten L-screw.

Step 3 For 62 cross support system:

Center the clamped cross support between side rails as shown in View 3.

For QPL cross support system:

Place the clamped cross supports between side rails, approximately 40 to 50 inches apart, as shown in View 4.

For KPL cross support system:


Place the clamped cross supports between side rails, approximately 40 to 50 inches apart, as shown in View 5.

Step 4 Secure cross supports to side rails as detailed in View 6.


Step 5 *Adjust glides to rest on the floor surface.* Lock glides in place by turning wing nuts tight against the plastic inserts.

For proper support, glides must rest on the floor surface and wing nuts must be tightened against the plastic inserts.


View 1




View 2




View 3




View 4




View 5



View 6



Wooden Side Rails



Metal Side Rails